



## 3 Phase Power Meter with RS232 Output and Free Software for connect to PC Computer.

### Features:

1. Measures 3-phase 3-wire circuit, 3-phase wire circuit, single-phase circuit.
2. True RMS value measurement on all scales.
3. 8,000 counts computerized chip gives a high resolution and accuracy.
4. Minimum current of Active Energy measure is 0.5A, it can measure expending energy per hour of general equipment. parameters are available Active Power, Apparent Power, Power Factor, Reactive power, Active Energy.
5. Double display two parameters on each each menu and stores 28 groups of parameters.
6. Measure five power parameters of each phase and total power value in three-phase measurement mode respectively..
7. Multifunctional button control, bar graph display the quick change of the measure for vision reading.
8. Windows software enable an easy download of the data from measurement.
9. In the Active Energy mode, you use power supply to power the meter for a long time measurement purpose.
10. It comes in a plastic carrying case and all accessories.  
Back light on the LCD display  
Minimum and Maximum memory.

### Technical Specifications:

- ACV: 100/300/600V. + 1.2% + 5 digits  
ACA: 40/100/400/1000A. + 2.-% + 5 digits.  
FREQ.: 20 Hz ~ 1 kHz. + 0.5%  
KVA: 4/10/40/100/600 kVA. + 3% + 5 digits.  
KW: 4/10/40/100/600 kW. + 3% + 5 digits.  
KVAR: 4/10/40/100/600 kVAR, + 4% + 5 digits.  
KWH: 10/100/1000/100,000 kWh. + 3% + 2 digits.  
PF: ( Cos  $\phi$  ) : 0.3 capacitive ~ 0.3 inductive. + 0.02  
Clamp Size  $\varnothing$ 50 mm. Max.  
Dimension: 282 X 104 X 47 mm.,  
Battery: 1.5V x 4. AA Size.  
Accessories: plastic carrying case. + Software + Cables.



สินค้าใหม่!

- Memory for 19 groups of measuring value.  
Weight: approx. 500 g.  
Warranty: 1 Year.

สนใจติดต่อ บริษัท เอเม็ท จำกัด